

## Activating Options

1. Go to Service Code 318 Activate Converter (Service Codes are found in the Set Up Mode). Here you should see all active and inactive converters. Inactive converters will be listed in Gray. If the Option is not grayed out (i.e., it is black) it is already activated.
2. Data Forward to the grayed out option you want and press Install (F6).
3. A different screen will appear on which you will see a Hardware Key serial number, a Converter Serial and a phone number to contact SWI Customer Support. You will also see a blank field labeled "Activation Password". If you already have your activation password, enter that in now and press Inc Set or Abs Set.
4. If you do not already have the activation password, write down the Hardware Key and Converter serial numbers shown on the screen and contact XYZ. After taking the serial numbers, XYZ will give you your password. Please note, this option is not free. If you have not placed an order for the required option, you will need to do so before we can give you the activation password.
5. After the password is entered, the Option is ready for use. Simply restart the ProtoTRAK system so that it recognizes the new software. For the ProtoTRAK CNC on your machine, do the shut down procedure and then turn the ProtoTRAK back on to allow it to reboot. For a ProtoTRAK Offline, it will not be necessary to restart the computer. Simply close the ProtoTRAK Offline application and then start it again.